

**Common Abbreviations Used**

AG auto transmission GS manual transmission

LAB left hand bank RAB right hand bank LLE left hand drive RLE right hand drive

Part Number<sup>1</sup> i.e. 0 258 006 123<sup>1</sup> Indicates Post Cat (Diagnostic) Sensor.


<b>Applause</b>							
1.6 i,i4WD	1,6	77	HDE Kat.	06.89-07.97	W08		0 258 986 501
					W50	0 258 001 027	
<b>Charade</b>							
1.0 i	1,0	40	CB Kat. SOHC	11.90-12.92	W08	0 258 986 501	0 258 986 501
1.3 i,i16V,i4WD	1,3	66	HCE Kat. SOHC; HCE OHC Kat.	06.88-12.92	W08		0 258 986 501
					W50	0 258 001 027	
<b>Cuore</b>							
850 [L5]	0,8	31/32	ED20 Kat.	08.94-12.99	W08		0 258 986 501
					W50	0 258 001 027	
,4WD [L8]	0,8	30-32	ED	A,CH,NL 11.87-02.90	MG5,W08		0 258 986 501
					MG5,W50	0 258 001 027	
<b>Feroza</b>							
1.6 i16V 4WD	1,6	70	HDE Kat.	12.89-12.95	KZO,W08	0 258 986 501	0 258 986 501
				05.92-08.93	W08	0 258 986 501	0 258 986 501
				D 09.90-08.93	W08	0 258 986 501	0 258 986 501
							DAIHATSU ►

# Common Abbreviations Used

**AG** auto transmission    **GS** manual transmission

**LAB** left hand bank    **RAB** right hand bank    **LLE** left hand drive    **RLE** right hand drive

**Part Number<sup>1</sup>** i.e. **0 258 006 123<sup>1</sup>** Indicates Post Cat (Diagnostic) Sensor.



◀ **DAIHATSU**

**Move**

850

0,9

31

ED20 SOHC Kat.

01.97-09.98

W08

W50

0 258 986 501

0 258 001 027