

**Common Abbreviations Used** AG auto transmission GS manual transmission  
**LAB** left hand bank **RAB** right hand bank **LLE** left hand drive **RLE** right hand drive  
**Part Number<sup>1</sup>** i.e. **0 258 006 123<sup>1</sup>** Indicates Post Cat (Diagnostic) Sensor.

<b>MG 25</b>							
105	1.4i 16V [ZR]	1,4	76	K-Serie <105>			
				Fg.Nr. YD 471565→	10.01→	W16	0 258 006 290
				Fg.Nr. →YD 471564	10.01→	W10	0 258 003 229
						W16	0 258 986 506
<b>120 1.8i 16V [ZR]</b>							
		1,8	86	K-Serie <120>			
				Fg.Nr. YD 522573→	10.01→	W16	0 258 006 127
				Fg.Nr. →YD 471564	10.01→	W10	0 258 003 229
						W16	0 258 986 506
<b>160 1.8i 16V [ZR]</b>							
		1,8	118	<VVC,K-Serie>			
				Fg.Nr. YD 471565→	10.01→	W16	0 258 006 289
				Fg.Nr. →YD 471564	10.01→	W10	0 258 003 229
						W16	0 258 986 506
<b>MG 45</b>							
120	1.8i 16V [ZS]	1,8	86	K-Serie <120>	10.01→	W16	0 258 006 127
							0 258 006 127 <sup>1</sup>
<b>MGF</b>							
1.6	i 16V	1,6	82	K-Serie <DOHC>			
				Fg.Nr. YD 522573→	10.01-03.02	W16	0 258 006 127
				Fg.Nr. →YD 522572	10.01-03.02	W10	0 258 003 229
						W16	0 258 986 506
<b>1.8 16V 160 SE Trophy, i 16V</b>							
		1,8	88/107/ 118	18K4F <K-Serie>; 18K4K <MPI VVC K-Serie>; K-Serie <MPI VVC>			
				Fg.Nr. YD 522573→	10.95-03.02	W16	0 258 006 127
				Fg.Nr. →YD 522572	10.95-03.02	W10	0 258 003 229
						W16	0 258 986 506
<b>TF</b>							
120	1.8i 16V Stepspeed	1,8	88	K-Serie <DOHC>	03.02→	W16	0 258 006 127 <sup>1</sup>
				Fg.Nr. YD 522573→	03.02→	W16	0 258 006 127
				Fg.Nr. →YD 522572	03.02→	W10	0 258 003 229
						W16	0 258 986 506
<b>135 1.8i 16V</b>							
		1,8	100	K-Serie <DOHC>	03.02→	W16	0 258 006 127 <sup>1</sup>
				Fg.Nr. YD 522573→	03.02→	W16	0 258 006 127
				Fg.Nr. →YD 522572	03.02→	W10	0 258 003 229
						W16	0 258 986 506
<b>160 1.8i 16V</b>							
		1,8	118	VVC K-Serie <DOHC>	03.02→	W16	0 258 006 127 <sup>1</sup>
				Fg.Nr. YD 522573→	03.02→	W16	0 258 006 127
				Fg.Nr. →YD 522572	03.02→	W10	0 258 003 229
						W16	0 258 986 506

M